

Cream whisk

First Summarize

Series of xnj brand mixers are some mixers we study successfully to take import mixers. It adopts the mechanism of constant torque with step less speed change and over-high speed planetary transmission with machines. The spare parts touching food are made of advanced stainless steel which is accordant with our national relevant standards on public hygiene.

The series has the features of nice appearance convenient to operate, safe and hygienical characteristic, and it can produce effectively. Be extensively suitable for hotels, Groceries, bakeries etc also can stir materials for factories and mine units, such as pharmaceutical factory and chemical raw material company etc.

Second、Technology Paramter

Model	Voltage	speed	Dimension	Net Weight
B5	110V/220V/50HZ/60Hz	100/1000rpm	390*240*430	15kg
B7	110V/220V/50HZ/60Hz	100/1000rpm	390*240*430	16kg
B8	110V/220V/50HZ/60Hz	100/1000rpm	390*240*430	17kg

Third 、Installatio

- 1、The machine should place in the ventilative, dry horizontal surface and should be proofed horizontal, so that the machine is calm and reliable
- 2、The pressure should be accordant with our introduction and the make of turing direction can be used after the wire is connected firmly.

Fourth 、the operating method

- 1、Relax arm handle tight, raise the machine's head install the head
- 2、Put the stainless steel on the bucket till it inserts concave groove, and fit it according to concave groove's direction at the end of the bucket.
- 3、Put in the mixing materials, put down the head, lock up the arm handle tight adjust the moving aim handle to the lowest speed start the switch, then adjust the machine according to the speed you need. (Operials according to anti-direcion after finishing the work)

Fifth、Points for attention

- 1、Hand sundry things etc are forbidden to stretch in the bucket when the machine do the work, in order to ensure safety.
- 2、Plug must be pulled out before cleaning please using slight wet and soft cloth not liquid or cleaners of spring style.
- 3、Had better not use the machine in the bed days In the bed days plug has better be pulled out.
- 4、Don't use high speed when there is nothing in the bucket
- 5、Electrical outlet must have good connecting ground wires

Sixth、Machine's characteristics

It has the function of over-high planetary transmission with machine, reliable function, adjusting speed by constant torque with step less speed change, the head can be raised, and it has functions of overload protection and switch on the lock.

Seventh、Possible breakdown and overcoming measures

- 1、Don't work after starting ---examine whether the power has electricity and outlet is good or not.
- 2、Stop work when working---examine fuse-wire at the back of the machine (fuse-wire is 5A)
- 3、The steel wire of mixing ball hit the bucket-adjust the steel wire till it is good completely by yourself.
- 4、The head can't be raised ---examine arm handle closed tight.
- 5、The mixing ball can't be taken out---the rotating direction is wrong

Attention : the power must be cut off when cleaning and keeping in good repair